

Installation Photos

STEP 1



Unroll DMX AG Underlayment™ (dimples facing down).

STEP 2



Lay 5/8" plywood or OSB on top of DMX AG Underlayment™.
Anchor to the concrete using tap con screws.

STEP 3



Lay laminate foam underlayment on top of plywood or OSB.

STEP 4



Lay laminate flooring. Job Finished!